

Fencer Installation with Center Pole Option



Install control panel on a secure mounting location to the opening side of your gate into the machine. A licensed electrician must do in the installation of all the wiring.

Install fencer underneath the control panel. Fencer should not be in direct weather elements.

Feed the wire through a bottom electric access hole and wire the Red wire into the DC+ and the black wire into the DC-.

The DC terminals have already been converted to 12 volt power.

Use approved under gate cable to run from the positive terminal on the fencer to the brushed attached to the slip ring under the machine. Picture 1. Under gate cable is to be installed in the other conduit. Note: Should not be installed in the same conduit as the power wiring.

Drive the ground rod supplied into the ground next to your control panel. Connect from the negative terminal on the fencer to the top of the ground rod.

Odyssey Performance Limited

4919 7th Line Eramosa, RR#4, Rockwood, ON. N0B 2K0

1-800-461-3362

Ph: 519-856-9959 Fax: 519-856-4141

email: sales@horseexerciser.com

www.horseexerciser.com

